

# Magic Eraser Playfield Cleaner Instructions

## By [www.PinballMagic.com](http://www.PinballMagic.com)

### Additional Supplies Needed

Cotton Rags, Window Cleaner, Isopropyl (Rubbing) Alcohol, Carnauba Wax, Novus 2 (Optional)

### **-Disclaimer-**

In order to use this product, you must access the inside of your pinball machine. **Hazardous voltages** are present at some locations under the playfield. **TURN OFF** the machine **BEFORE** using this product. You assume **SOLE RESPONSIBILITY** for any incidental damage, consequential damage, or personal injury to people or property caused by the use of this product. Not recommended for use on enamel or acrylic paints. Do not use with chlorine bleach or any cleaner other than specified in the instructions. This product is non-toxic when dry, but may be a skin irritant when used with another product. If you have sensitive skin, use rubber gloves for application. Do not use this product if you are pregnant or nursing. Keep out of reach of children, toddlers, and pets. The sponge applicator may start to disintegrate after many uses. This may cause small particles to be released into the air when the applicator is handled when dry. Use caution when applying more than 15 to 20 circular motions with the Eraser.

The sponge applicator included in this kit is coated with a special cleaning agent. Using rubbing alcohol activates the sponge's cleaning power.

1. Start with a small area (3 inch by 3 inch) and wipe the playfield with the sponge in a small, circular motion. Use moderate pressure. For better results, alternate direction after a few circular motions. You will start to see the dirt disappear from the cracks in your playfield after about 6 circular motions. Be sure to check the area you are cleaning after a few motions to see if there is paint loss. Wipe off excess alcohol with a cotton rag. If you start to notice the wood warping or "raising grain", stop using the applicator and let the area air dry for one hour. Note: If you use this product for more than 15-20 circular motions, paint may start to wear off. **PROCEED AT YOUR OWN RISK.**
2. After you have cleaned the first 3 by 3 area, move on to another area and repeat step 4 until you are finished.
3. Apply a coat of Novus 2 (optional) to the areas you cleaned with the sponge applicator. Wax the area cleaned area with a quality Carnauba wax.
4. This product does not remove the cracks in your playfield. It removes the dirt that was once in them. To prevent more dirt from accumulating in the cracks, keep the playfield clean and replace the balls on a regular basis. You can also apply a clearcoat to protect the playfield. Email [Info@PinballMagic.com](mailto:Info@PinballMagic.com) for more information.
5. Re-install the playfield glass and your all done!

QUESTIONS? COMMENTS?

Feel free to email me [Info@PinballMagic.com](mailto:Info@PinballMagic.com)